

BUILT TO LAST



WESTERN STAR & FREIGHTLINER TRUCK SHOCK ABSORBERS

**24 MONTH
150,000KM
WARRANTY**

Shock absorbers engineered and manufactured with proven durability to improve your **UPTIME**



MONROE #	TYPE	APPLICATION	OE PART #
F5490	Drive	Neway AD Drive Axle	90045132, 90045504,
T5488	Drive	Neway AD Drive Axle	3501001, 21126793,
T5489	Drive	Neway AD Drive Axle	90045534
T5494	Drive	Freightliner & Western Star Drive with Airliner Suspension	1618708000, 471700002809, 090-2648
T5495	Steer	Freightliner & Western Star Steer with Airliner Suspension	902647, 090-2647, 1013809000
66957	Steer	Refer OEM	37301-3401, 57252
66902	Steer	Refer OEM	676081
66178	Cabin	Link Cab Suspension	1201-0012, 1202-001.2
66149	Cabin	Refer OEM	66010-3402, 66010-3403, 66010-3404, 725470
66196	Cabin	Refer OEM	66010-3406, 83027

*Note: For further application listings or OE search please refer to monroe.com.au
66 Series designed for 90% on-highway, 10% off-highway use only